

# CABINET HARDWARE HELPER

## FINISH

Finishes are listed, in our catalog, for each product according to availability. If a finish is not listed, it is not manufactured in that finish.

## SIZE

Some measurements are in millimeters. Knobs are detailed with approximate diameters or overall dimensions. Pulls and Handles are detailed with the drilling distance or center-to-center measurement. Here are some typical conversions to inches. The equivalent measure in inches is an approximation.

### KNOB DIAMETER:

20mm = approx. 13/16"

25mm = approx. 1"

30mm = approx. 1 3/8"

### PULL & HANDLE DRILLING DISTANCE:

64mm = approx. 2 1/2"

96mm = approx. 3 3/4"

128mm = approx. 5"

160mm = approx. 6 5/16"

The general formula for conversion:

**MILLIMETERS x .0394 = INCHES**

For example: 96 x .0394 = 3.78 (approximately 3 3/4")

## INSTALLING YOUR CABINET HARDWARE

Your order will include 4mm break-off screws divided in 5mm increments that can be snapped off at the required length for your drawer or door front. HI LINE does not recommend pre-drilling holes before you receive your hardware. If you are replacing existing pulls remember that the conversion from millimeters to inches is an approximation, and an exact equivalent.